

MIDI

MIDI SOLUTIONS F8 MIDI FOOTSWITCH CONTROLLER



The MIDI Solutions F8 8-input MIDI Footswitch Controller provides eight 1/4 inch phone jack inputs for connection to footswitches or contact closures which can be used to trigger MIDI events. Triggered MIDI events are merged with incoming MIDI messages and sent to the MIDI output of the F8.

The Polarity of each footswitch can be determined automatically on power-up, or can be programmed to normally-open or normally-closed. Its also possible for the F8 to send out the state of its footswitches immediately on power-up rather than waiting for each to be depressed. The F8 is MIDI-powered, and requires no batteries or power supply to operate with most MIDI products. A MIDI indicator LED lights up when the product is powered and flashes when MIDI data passes through it.



Features:

• Triggered event types are programmable and include:

- Note Control Change
- Pitch Bend
- Program Change
- Start/Stop
- System Exclusive



Orbital Sound Ltd, 57 Acre Lane,
Brixton, London, SW2 5TN,
United Kingdom,
Tel: +44 207 501 6868
hire@orbitalsound.com
www.orbitalsound.com